

Stackable chair in beech plywood, with clear-varnished seat and back, whose unique features are ergonomics, comfort of use, active and passive safety.

Ergonomics and comfort of use are guaranteed by studying the most correct inclinations for sitting posture and by the dimensions of the seat itself.

Active safety derives from the study of shapes, weights and their distribution, which give the user the feeling of safety in the grip of the armrest and the feeling of stability of the product when seated. Moreover the handling of the chair is easy thanks to its low weight.

Lastly, passive safety is guaranteed by the rounded shapes of the armrests (if provided) and other construction details like the absence of sharp corners and edges that make the chair anti-trauma and limit injuries.



MODELS AND TECHNICAL SPECIFICATIONS

Code	Description	Height	Width	Depth
1611203	Without armrests	82 cm	51 cm	53 cm
1611204	With armrests	82 cm	56 cm	59 cm

From a structural point of view, the armchair is composed of:

- 2 sides or shoulders in lamellar beech wood (made of curved parts with a section of 30 x 30 mm);
- 1 under seat supporting structure in solid beech wood;
- 1 exposed plywood seat (12 mm thick);
- 1 exposed plywood backrest (25 mm thick).

Dimensions for chair without armrests Code 1611203	Dimensions for chair with armrests Code 1611204
Width 51 cm	Width 56 cm
Height 82 cm	Height 82 cm
Seat height 46 cm	Armrest height 65 cm
Overall depth 53 cm	Seat height 44 cm
Approx. max user weight 110 kg	Overall depth 59 cm
	Approx. max user weight 110 kg

The chair is assembled with screws that guarantee the stability of the seat even after a long use. If the screws loosen with use, with simple and inexpensive screw tightening interventions, you have the guarantee of the product's stability over time.

We varnish the exposed wooden parts with a water-based immersion paint cycle suitable for indoor use that leaves the wood grain visible, a polyurethane primer and a matt polyurethane finish cycle, both applied with electrostatic guns.

FISIOTECH SRL

Operating headquarters: Via Toniolo, 44/E-F - 31028 Vazzola (TV) - ITALY

Registered office: Via Valdoni, 19 - 31013 Cimavilla di Codognè (TV) - ITALY

Tel. +39 0438470342 - Fax +39 0438478762 - mail : info@fisiotech.com - pec : fisiotech@emailsec.it

VAT Number IT 03765100262 - Rea TV 296956